

	Vendor #	6	5	4	3	2	1	
Test	Objects Tested	Status	Status	Status	Status	Status	Status	Remarks
4.1.1		P	P(a)	P	F(b)	P	P	Host Resources Storage Group Passed
	hrMemorySize							(a) Storage Table Empty
	hrStorageSize							(b) error noSuchName getting hrMemorySize
	hrStorageTypes							
	hrStorageType							
	hrStorageDescr							
	hrStorageUsed							
4.1.2		F(b)	P	F(a)	P	P	P	Host Resources Device Table test Passed
	hrDeviceTypes							(a) Unexpected Status
	hrDeviceType							(b) Print Table Error
	hrDeviceStatus							
	hrDeviceDescr							
	hrDeviceProcessor							
	hrDeviceNetwork							
	hrDevicePrinter							
	hrDeviceDiskStorage							
4.1.3		P	P	P	P	P	P	Processor Table Empty
	hrDeviceType							
	hrProcessorLoad							
	hrDeviceProcessor							
4.1.4		P	P	P	P	P	P	Host Resources Network Table test Passed
	hrDeviceNetwork							
	hrDeviceType							
	hrNetworkIfIndex							
	ifAdminStatus							
	hrDeviceStatus							
4.1.5		P	P	P	P	P	P	Host Printer Table test Passed
	hrDeviceType							
	hrDeviceStatus							
	hrDeviceDescr							
	hrDevicePrinter							

	Vendor #	6	5	4	3	2	1	
Test	Objects Tested	Status	Status	Status	Status	Status	Status	Remarks
4.1.6		P	P	P	P	P	P	Disk Storage Table Empty
	hrDeviceDiskStorage							
	hrDeviceType							
	hrDiskStorageCapacity							
	hrDiskStorageMedia							
	hrDiskStorageRemoveble							
	hrDiskStorageAccess							
4.1.7		P	P	P	P	P	P	Partition Table Empty
	hrPartitionLabel							
	hrPartitionSize							
	hrPartitionFSIndex							
	hrFSMountPoint							
4.1.8		P	P	F(a)	P	P	P	File System Table Empty
	hrFSTypes							(a) error noSuchName setting hrFSLastPartialBackupDate to 0x00:00:01:01:00:00:00:00
	hrFSMountPoint							
	hrFSRemoteMountPoint							
	hrFSType							
	hrFSAccess							
	hrFSBootable							
	hrFSLastPartialBackupDate							
	hrFSLastFullBackupDate							
5.1.1		P	P	P	P	P	P	Host Printer Table test Passed
	hrDeviceType							
	hrDeviceDescr							
	hrDevicePrinter							
5.1.2		F(d)	F(b)	P	F(c)	F(a)	P	Host Resources Device Status Test Passed
	hrDeviceStatus							(a)(b)(c)(d) Unexpected hrPrinterStatus
	hrPrinterStatus							
	hrPrinterDetectedErrorState							
5.2.1		P	P	P	F(b)	F(a)	P	Responsible Party Group Passed
	prtGeneralCurrentOperator							(a) error noSuchName setting - prtGeneralCurrentOperator to New Operator
	prtGeneralServicePerson							(b) error noSuchName getting prtGeneralCurrentOperator

	Vendor #	6	5	4	3	2	1	
Test	Objects Tested	Status	Status	Status	Status	Status	Status	Remarks
5.2.2		P	F(b)	P	P(c)	F(a)	P	Cover Table Test Passed
	prtCoverStatus							(a) Unexpected result
	prtCoverDescription							(b) No test option chosen; test aborted
	prtGeneralCurrentLocalization							(c) run multiple times
5.2.3		P	P	P	P	P	P	General Printer Group Test Passed
	prtGeneralReset							
5.2.4		F(e)	F(c)	P	F(d)	F(a)	F(b)	(b) (c) (d) error noSuchName setting prtMarkerDefaultIndex to 1
	prtGeneralReset							(a) error noSuchName setting prtGeneralCurrentOperator to Operator 2
	hrPrinterStatus							(e) Reset to Factory defaults failed
	hrDeviceStatus							
	prtMarkerPowerOnCount							
	prtMarkerLifeCount							
	prtMarkerMarkTech							
	prtMarkerDefaultIndex							
	prtGeneralCurrentOperator							
5.3.1		F(f)(g)	F(c)	F(d)	F(e)	F(a)	F(b)	(b) (d) error noSuchName setting prtInputMediaDimFeedDirDeclared to 85000
	prtInputDefaultIndex							(a)(f) error noSuchName setting prtInputMediaDimFeedDirDeclared to 279400
	prtInputMediaName							(c) error genErr setting prtInputMediaDimFeedDirDeclared to 110000
	prtInputName							(e) error noSuchName setting prtInputMaxCapacity to 100
	prtInputDimUnit							(g) Unexpected Value
	prtInputCapacityUnit							
	prtInputType							
	prtInputStatus							
	prtInputMaxCapacity							
	prtInputCurrentLevel							

	Vendor #	6	5	4	3	2	1	
Test	Objects Tested	Status	Status	Status	Status	Status	Status	Remarks
5.3.1		F(e)	run once	P(c)	F(d)	F(a)	F(b)	(c) Input Table Test Passed
	prtInputDefaultIndex							(a)(e) Unexpected Value
	prtInputMediaName							(b) error noSuchName setting prtInputDefaultIndex to 5
	prtInputName							(d) error noSuchName getting prtInputName
	prtInputDimUnit							
	prtInputCapacityUnit							
	prtInputType							
	prtInputStatus							
	prtInputMaxCapacity							
	prtInputCurrentLevel							
5.3.2		F((f)	F(c)	F(d)	F(e)	F(a)	F(b)	(a) (b) (c) (e) (f) Prerequisite Test 5.3.1 Failed
	prtInputType							(d) Set failed
	prtInputDimUnit							
	prtInputMediaDimFeedDirDe clared							
	prtInputMediaDimFeedDirCh osen							
	prtInputMediaDimXFeedDirC hosen							
	prtInputCapacityUnit							
	prtInputMaxCapacity							
	prtInputCurrentLevel							
	prtInputStatus							
	prtInputMediaName							
5.3.3		F(f)	F(c)	P(d)	F(e)	F(a)	F(b)	(d) Extended Input Group test passed
	prtInputName							(a) (b) (c) (e) (f) Prerequisite Test 5.3.1 Failed
	prtInputVendorName							
	prtInputModel							
	prtInputVersion							
	prtInputSerialNumber							
	prtInputDescription							
	prtInputSecurity							
	prtGeneralCurrentLocalizatio n							

	Vendor #	6	5	4	3	2	1	
Test	Objects Tested	Status	Status	Status	Status	Status	Status	Remarks
5.3.4		F(f)	F(c)	P(d)	F(e)	F(a)	F(b)	(d) Input Media Group Passed
	prtInputMediaWeight							(a) (b) (c) (e) (f) Prerequisite Test 5.3.1 Failed
	prtInputMediaType							
	prtInputMediaColor							
	prtInputMediaFormParts							
5.4.1		F(d)	F(b)	P	P(c)	F(a)	P	Output Group Table Test Passed
	prtOutputDefaultIndex							(a) Set prtOutputDefaultIndex Failed
	prtOutputName							(b) error noSuchName setting prtOutputDefaultIndex to 2
	prtOutputType							(c) multiple attempts
	prtOutputStatus							(d) unexpected status
	prtOutputCapacityUnit							
	prtOutputType							
5.4.2		F(e)	F(b)	F(c)	F(d)	F(a)	P	Output Group Test Passed
	prtOutputType							(a)(b)(e) Prerequisite Test 5.4.1 Failed
	prtOutputCapacityUnit							(c)(d) Expected Alert in status (and didn't see it)
	prtOutputMaxCapacity							
	prtOutputRemainingCapacity							
	prtOutputStatus							
5.4.3		F(d)	F(b)	P	F(c)	F(a)	P	Extended Output Group test Passed
	prtOutputName							(a)(b)(d) Prerequisite Test 5.4.1 Failed
	prtOutputVendorName							(c) error noSuchName getting prtOutputName
	prtOutputModel							
	prtOutputVersion							
	prtOutputSerialNumber							
	prtOutputDescription							
	prtOutputSecurity							
	prtGeneralCurrentLocalizatio n							
5.4.4		F(d)	F(b)	NR	NR	F(a)	F(cef)	(c) error noSuchName getting prtOutputDimUnit
	prtOutputDimUnit							(a)(b)(d) Prerequisite Test 5.4.1 Failed
	prtOutputMaxDimFeedDir							(e) error noSuchName getting prtOutputMaxDimFeedDir
	prtOutputMaxDimXFeedDir							(f) prtOutputDimensionsGroup not implemented
	prtOutputMinDimFeedDir							
	prtOutputMinDimXFeedDir							

	Vendor #	6	5	4	3	2	1	
Test	Objects Tested	Status	Status	Status	Status	Status	Status	Remarks
5.4.5		F(c)	F(b)	P	P	F(a)	P	Output Features Group Passed
	prtOutputStackingOrder							(a) (b) (c) Prerequisite Test 5.4.1 Failed
	prtOutputPageDeliveryOrientation							
5.5.1		P	F (b)	P	F(c)	P	F(a)	Marker Table Test Passed
	prtMarkerCounterUnit							(a) (b)(c) error noSuchName setting prtMarkerDefaultIndex to 1
	prtMarkerStatus							
	prtMarkerPowerOnCount							
	prtMarkerLifeCount							
	prtMarkerAddressabilityUnit							
	prtMarkerMarkTech							
	prtMarkerProcessColorants							
	prtMarkerSpotColorants							
	prtMarkerMarkTech							
	prtMarkerDefaultIndex							
	prtMarkerNorthMargin							
	prtMarkerSouthMargin							
	prtMarkerEastMargin							
	prtMarkerWestMargin							
	prtMarkerAddressabilityFeedDir							
	prtMarkerAddressabilityXFeedDir							

	Vendor #	6	5	4	3	2	1	
Test	Objects Tested	Status	Status	Status	Status	Status	Status	Remarks
5.5.2		P	F(b)	P	F(c)	P	F(a)	Marker Group Test Passed
	prtMarkerAddressabilityUnit							(a) (b)(c) Prerequisite Test 5.5.1 Failed
	prtMarkerAddressabilityFeedDir							
	prtMarkerAddressabilityXFeedDir							
	prtMarkerNorthMargin							
	prtMarkerSouthMargin							
	prtMarkerEastMargin							
	prtMarkerWestMargin							
	prtMarkerSuppliesType							
	prtMarkerPowerOnCount							
	prtMarkerLifeCount							
5.5.3		P(d)	F(b)	P	F(c)	P(a)	P	Marker Supply Table Test Passed
	prtMarkerSuppliesColorantIndex							(a) prtMarkerSuppliesTable is empty
	prtMarkerSuppliesMarkerIndex							(b)(c) Invalid type 1 enumeration
	prtMarkerSuppliesClass							(d) prtMarkerSuppliesTable is empty
	prtMarkerSuppliesSupplyUnit							
	prtMarkerSuppliesMaxCapacity							
	prtMarkerSuppliesLevel							
	prtMarkerStatus							
	prtMarkerColorantRole							
	prtMarkerSuppliesDescription							
	prtGeneralCurrentLocalization							
5.5.4		P(c)	P	P	P(b)	P	P(a)	Marker Colorant Table Test Passed
	prtMarkerColorantMarkerIndex							(a)(b)(c) Marker Colorant Table Empty
	prtMarkerColorantRole							
	prtMarkerColorantTonality							
	prtMarkerStatus							

	Vendor #	6	5	4	3	2	1	
Test	Objects Tested	Status	Status	Status	Status	Status	Status	Remarks
5.6.1		P	F(a)	P	P	P	P	Media Path Table Test Passed
	prtMediaPathMaxSpeedPrintUnit							(a) Invalid Speed Value
	prtMediaPathMediaSizeUnit							
	prtMediaPathType							
	prtMediaPathStatus							
	prtMediaPathMaxSpeed							
	prtMediaPathDescription							
	prtMediaPathDefaultIndex							
5.6.2		P	F(b)	P	F(c)	F(a)	P	Media Path Group Test Passed
	prtMediaPathMaxMediaFeedDir							(a) Unexpected result
	prtMediaPathMaxMediaXFeedDir							(b) Prerequisite Test 5.6.1 failed
	prtMediaPathMinMediaFeedDir							(c) error noSuchName setting prtGeneralCurrentLocalization to 2
	prtMediaPathMinMediaXFeedDir							
	prtMediaPathMediaSizeUnit							
	prtMediaPathType							
	prtMediaPathDescription							
	prtGeneralCurrentLocalization							
5.7.1		F(d)(e)	NR	NR	F(c)	F(b)	F(a)	(a) error noSuchName setting prtChannelState to 4
	prtChannelType							(b) ifInOctets.2 did not increase enough
	prtChannelState							(c) error noSuchName getting prtChannelIfIndex
	prtChannelStatus							(d) noSuchName getting ifInOctets
	prtChannelIfIndex							(e) Invalid reference to ifTable (second try)
	ifAdminStatus							
	ifInOctets							
	prtInterpreterLangVersion							

	Vendor #	6	5	4	3	2	1	
Test	Objects Tested	Status	Status	Status	Status	Status	Status	Remarks
5.8.1		P(d)	F(b)	P	F(c)	F(a)	P	Interpreter Group test Passed
	prtInterpreterLangFamily							(a) Orientation changed not validated
	prtInterpreterDefaultOrientation							(b) (c) error noSuchName setting prtGeneralCurrentLocalization to 2
	prtInterpreterTwoWay							(d) passed after multiple attempts
	prtInterpreterDescription							
	prtGeneralCurrentLocalization							
5.9.1		F(c)	F(b)	P	P	F(a)	P	The Console Group Test has Passed
	prtConsoleNumberOfDisplayLines							(a)(c) error noSuchName setting prtConsoleDisable to 4
	prtConsoleNumberOfDisplayChars							(b) Unexpected Value
	prtConsoleLocalization							
	prtConsoleDisable							
	prtConsoleLocalization							
	prtLocalizationLanguage							
5.9.2		F(f)	F(c)	F(d)	F(e)	F(b)	F(a)	(a) timeout error on SET
	prtConsoleDisplayBufferText							(b) (d) (e) (f) error noSuchName setting prtconsoleDisplayBuffer Text to XXX
								(c) error genErr setting prtConsoleDisplayBufferText to XXX
5.9.3		P	P(b)	P(c)	P	F(a)	P	Console Light Table test Passed
	prtConsoleOnTime							(a) Unexpected Result
	prtConsoleOffTime							(b) (c) Console Light Table Empty
	prtConsoleDescription							
5.10.1		P(f)	P(c)	F(d)	P(e)	F(a)	F(b)	(a) (b)(d) Printer did not issue an expected trap
	printerV1Alert							(c) (e) (f) Printer doesn't send traps
	hrDeviceStatus							
	hrPrinterStatus							
	hrPrinterDetectedErrorState							
5.10.2		P(f)	P(c)	F(d)	P(e)	F(a)	F(b)	(a) (b)(d) Printer did not issue an expected trap
	printerV1Alert							(c) (e) (f) Printer doesn't send traps
	hrDeviceStatus							
	hrPrinterStatus							

	Vendor #	6	5	4	3	2	1	
Test	Objects Tested	Status	Status	Status	Status	Status	Status	Remarks
	hrPrinterDetectedErrorState							
5.10.3		P(f)	P(c)	F(d)	P(e)	F(a)	F(b)	(b) (d) Printer did not issue an expected trap
	printerV1Alert							(a) Test was cancelled
	hrDeviceStatus							(c) (e)(f) Printer doesn't send traps
	hrPrinterStatus							
	hrPrinterDetectedErrorState							
5.10.4		P(f)	P(c)	F(d)	P(e)	F(a)	F(b)	(b)(d) Printer did not issue an expected trap
	printerV1Alert							(a) Test was cancelled
	hrDeviceStatus							(c) (e)(f)Printer doesn't send traps
	hrPrinterStatus							
	hrPrinterDetectedErrorState							
	hrPrinterDetectedErrorState							